



# U47A Repair Guide

## U47A Block Diagram




&lt;Core Design&gt;


# POWER FLOW



## POWER ON SEQUENCE



## Voltage & Signal Measure Point TOP



1091f  
1071f

