



X401U Repair Guide


X401U Schematic R1.2



POWER FLOW



POWER ON SEQUENCE



Voltage & Signal Measure Point Bottom

